

Product Datasheet

Water Treatment Additive

Ideal for use with Hughes self-contained eye wash units such as the STD-68G or OptiWash® to prevent bacteria growth and prolong the water quality. One 236ml bottle preserves 15-76 litres of water.

The eye wash unit should be cleaned and refilled every 120 days when using the water preservative.

Note:

- Do not change dilution or use with other chemicals
- Do not reuse after application
- Do not use if seal is missing or broken
- Batch number printed on bottle
- Once opened, use entire contents and discard (expiration date only applies to a sealed bottle)

Seek medical advice if you have any of the following during or after use:

- Changes in vision
- Eye pain
- Condition worsens or persists
- Continued redness or irritation of the eye
- If swallowed



Specifications

| MATERIALS | |
|---------------------|--|
| INGREDIENTS | Chlorhexidine 1% w/v Purified Water Propylene Glycol |
| SERVICES | |
| USEAGE | For use with self-contained emergency eye wash units |
| WARNING | For external use only. In case of contact with eye in undiluted form, flush with clean water |
| STORAGE TEMPERATURE | Between 20C / 68F and 25C / 77F |